
## Installing Revox PR99 PAUSE MEMORY

Before installing you have the possibility to choose between two different modes for Pause Memory PR99:


Jumper = small red bridge connector on the board

Standardfunction
 Jumper on BOTH pins
 (as delivered):




- recording starts immediately
- just pause memory is working.
- Pressing any button initiates the desired reel movement

special functionJumper just to ONEof the pins:




- > Connecting the jumper to one pin, you can switch from PAUSE to PLAY or REC, preventing the PR99 to start running.
- > Recording starts without a clicking sound.
- ➤ Reel funktion PLAY or REC is started then by pressing PAUSE button again.



Unscrew the four phillips screws on the backside of the PR99 case:


PR99 Pause Memory page 2

This connector is to be pulled out




Pull connector out stabilize the board with your other hand

Plug connector in module PR99 Pause Memory





PR99 Pause Memory page 3



Plug in PR99 Pause Memory using the other hand for counter-pressure

PR99 Pause Memory installed





installing complete – enjoy your new Pause Memory!